# Strong and weak current cables need to be routed in separate cable trays



## Overview

Cable Separation Standards Why It Matters: High-voltage and limited energy circuits routed too closely can cause cross-talk, distortion, or packet errors.

## Key Takeaways

Strong (high-voltage) and weak (low-voltage) current cables should always be routed in separate cable trays to prevent interference, ensure safety, and comply with standards.

### Importance of Separation

Strong current cables carry high voltage and current (typically 220V and above) for powering equipment, while weak current cables transmit low-voltage signals (below 36V) for data, voice, and control systems. Mixing these cables in the same tray can cause electromagnetic interference (EMI), signal distortion, network interruptions, and even fire hazards. Nearly 40% of electrical accidents are linked to improper mixing of strong and weak current cables.

### Recommended Practices

Separate Cable Trays: Use independent trays for strong and weak current cables. Electrical trays are typically positioned above instrumentation or signal trays to minimize EMI. Minimum Spacing: Maintain at least 300mm (12 inches) of horizontal or vertical separation between power and signal cables.

© 2026 CJC FIBRE CONSULTANTS - All rights reserved

If crossing is unavoidable, cables should intersect at angles of 60° or more. Use of Dividers: In congested areas, metal partitions or divider brackets can be installed within trays to prevent interference. Shielding: Weak current cables in high-interference environments may require additional shielding, such as aluminum foil and copper mesh, to reduce high-frequency interference by up to 60%.

Faraday Cage Effect: For weak current tubes crossing strong current lines, galvanized steel tubes grounded at both ends can provide effective shielding. Compliance with StandardsNEC 2026: Articles 300. 3(C), 725.

136, 760. 53/760. 136, and 805 outline separation rules for power and limited energy circuits, including the use of separate raceways or metallic barriers when minimum spacing cannot be maintained.

TIA-569-E: Provides spacing guidelines to prevent EMI in communications cabling.

IE

C 61000-5-2: Recommends routing cables close to metal structures and maintaining proper spacing to control electromagnetic coupling.

### Summary

Routing strong and weak current cables in separate trays with proper spacing, shielding, and dividers is essential for signal integrity, safety, and regulatory compliance. Following these practices reduces EMI, prevents accidents, and ensures reliable operation of both power and communication systems.

## Article Content

Cable Separation Standards

Why It Matters: High-voltage and limited energy circuits routed too closely can cause cross-talk, distortion, or packet errors, especially in dense cable trays or congested ceiling spaces.

Cable Tray Fill Rules (NEC 392)

This guide covers the cable tray types and their appropriate applications, the fill rules for each configuration, ampacity derating requirements, separation of power and signal cables, and the

Core Principles for Electrical and Instrumentation Cable Tray Layouts

Layered Separation: Strong current and high-voltage cables are positioned apart from low-current, low-voltage instrumentation cables. Layered separation reduces interference, preserving the quality of

*© 2026 CJC FIBRE CONSULTANTS - All rights reserved*

NEC Standards for Cable Trays: What Every Installer Needs to Know

This article provides a comprehensive framework that governs various aspects of cable tray installations, including the types of cables that are deemed acceptable for use, requirements for

Cable Tray Spacing Standards for Installation and Safety

Discover the essential cable tray spacing requirements for safe and efficient installation. Learn key standards, horizontal and vertical spacing, and more.

EMC implementation

The physical separation of high and low-current cables is very important for EMC, particularly if low-current cables are not shielded or the shielding is not connected to the exposed

Essential Guide to Cable Tray Segregation and Compliance

This guide outlines cable tray segregation techniques for improved safety and reliability in electrical cable management.

Explaining NEC Article 392 on Cable Trays

Cables and conductors must be secured to the cable tray at intervals according to installation instructions. For non-horizontal runs, cables should be fastened securely to transverse

Cable Tray Systems: Requirements and Best Practices

This article explains the main requirements and good practices for cable tray systems, including tray types, materials, loading, supports, bonding, cable selection, and installation details.

Separation of power cables and signal cables

Separate the cables into relevant cable groups – power cables and signal cables and unshielded mains power inputs. Only bundle cables of the same cable group together. Always lay the

Strong vs Weak Cable Installation Guide

Strong current cables carry high voltage and high current of 220V and above, and are responsible for driving power equipment such as lighting and air conditioning;

Wiring in Cable Trays: Your Guide to Tidy and Safe

Learn essential principles for wiring in cable trays. Our guide covers segregation, fill, bending, grounding, and labeling for safe, tidy, and reliable cable

*© 2026 CJC FIBRE CONSULTANTS - All rights reserved*

Cable Tray Spacing Standards for Installation and Safety

The Importance of Cable Tray Spacing in Electrical Infrastructure Cable tray spacing is a critical aspect of electrical infrastructure, influencing both

General Cable Routing Principles

Also, cables can be routed through a cable tray that is installed on the top of the cabinet. The specifications, routing, cross-section, and location for cable routing should be predetermined, and the

Understanding cables commonly used in high and low current systems

Understanding the types of cables used in high and low current systems is essential for designing and maintaining safe and efficient electrical installations. By considering the current

Mixing Cables Over and Under 600V in Cable Tray

At times it becomes necessary, or even desirable, to route medium- or high-voltage cables (greater than 600V) in the same cable tray with cables rated 600V or less. Section 300.3 (C)

DC Cables and AC Cables Should Not Share Conduits or Trunking

One key principle that often gets overlooked is that DC (direct current) cables and AC (alternating current) cables should not share conduits or trunking. This is not just a

Explaining NEC Article 392 on Cable Trays

NEC Article 392 explains cable trays, their components, appropriate wiring methods for cable trays, and instances where they are and are not

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

*© 2026 CJC FIBRE CONSULTANTS - All rights reserved*

## Contact Us

Continue your research online:

Website: https://cjcconsultants.co.za
Technical inquiry: https://cjcconsultants.co.za/contact.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 CJC FIBRE CONSULTANTS - All rights reserved